

Using a FoodSaver to Seal the Meals in a Jar

Copyright: Please do not reproduce this lesson and give it to other people. Direct them to www.homemakingdivas.com

©www.homemakingdivas.com



The FoodSaver comes with a hose attachment that can be used with jar sealer attachments.



The Jar Attachments are designed for Ball® and Kerr® brand wide-mouth and regular-mouth mason jars.

Wide-mouth Jar Sealers can only be used with wide-mouth jars and the Regular Jar Sealers can be used with the regular mason jars.

The attachments have a rubber seal on the inside



The hose attaches to the Foodsaver and then the other end attaches to the top of jar sealer



Make sure the glass jar is clean and free from powdered food particles.

Put the Mason jar lid on top of the jar (do not put the metal band/ring on the jar, just the flat lid), and then fit the sealer attachment over the top of the jar lid.

Each model of Foodsaver is different and you should follow the instructions for the model that you own. Some Foodsavers need you to push the “Attachment” button. The model V3230, used in these instructions, needs to have the sealer door locked down into place before the hose will suck the air.

When you push the button to start the foodsaver it will vacuum all the air out of the jar and shut off automatically when all the air is out of the jar.






Remove the hose from the top of the sealer attachment to release the vacuum seal. Remove the jar sealer attachment from the jar. Place the metal ring on the jar and tighten it

If a meal has a lot of powder ingredients the jar may not seal because the powder can get sucked between the glass edge and the metal lid. To avoid this from happening place a paper inside the jar to help keep the powder in the jar. Use a paper towel and trace the shape of the metal lid.



Cut the ink line off when you are cutting the circles.

Fit the paper down inside of the jar. Make sure the paper is not up on the top glass rim when putting the lid on the jar



Note: The FoodSaver bags are not designed to store food for long term storage. You can use a Mylar bag but cannot use the bags designed for the FoodSaver

